

MEDEVAC4 STRETCHER – SETUP INSTRUCTIONS

STEP 1 – Release the tie straps.



STEP 2 – Straighten stretcher collapsible support rods.



STEP 3 – Hold both handles and rotate 90° outwards.



STEP 4 – While holding handles, push against cross rod and lock into place. Turn stretcher around and lock second rod into place.



STEP 5 – Fold stretcher by repeating same actions in reverse. Rotate (turn) handles inwards, fold joints and tie straps.