

PedalPureTM Water Filter System



PedalPureTM water filtration systems are designed for use in situations where electricity is not available. It is 100% manual powered, and suitable for use in rural or disaster struck areas. The system is able to produce potable water for up to 1000 persons per day.

PedalPureTM is maintenance free, and only requires cleaning of the ultra filtration membranes from time to time. The cleaning of the membranes is easy and only requires a simple back flush with clean water.

PedalPureTM comes equipped with wheels for easy transportation, and can be transported easily. The wheels are installed with easy to use brakes to prevent unwanted rolling.

PedalPureTM ultra filtration membranes filter suspended particles as small as 0.01 microns. PedalPureTM UF membranes are certified by third party test centres to filters away bacteria, suspended solid, colour etc.

Unique Presence Sdn Bhd No. 142, Jalan Sri Sulong 1, Taman Industri Sri Sulong, 83500 Parit Sulong, Batu Pahat, Johor Darul Ta'zim, Malaysia. T (+60) 7 410 2011 F (+60) 7 410 1009 Email: info@upsb.com.my Website: www.upsb.com.my (UPSB Malaysia) Unique Presence Sdn Bhd.

www.upsb.com.my | (UPSB Malaysia)

Technical Information		
Dry weight:	30kg	
Capacity:	up to 800L/hr	
MWCO:	200,000	

*Specifications are subject to change without prior notice.

Sample Marking

1. FILTERED (TREATED WATER)
2. FILTERED (NON-TREATES WATER)

Reported Date: 7th December 2011 Analyzed Date: 7th - 12th December 2011 Reported Date: 15th December 2011

On Analysis of sample(s) collected, the result(s) obtained are as follows:


Laboratory Test Report				
Parameters	Methods	Results (Sample Marking)		
		1	2	
Total Plate Count (cfu/ml) [Plate Count Agar, (37°C, 24 Hours)]	APHA 9215B	NG(<1)	2.0×10^3	
Total Plate Count (cfu/ml) [Plate Count Agar, (22°C, 72 Hours)]	APHA 9215B	NG(<1)	4.0×10^3	
Faecal Coliform Count (feacal coliform /100ml) [M-FC Medium Agar, (44.5°C, 24Hours)]	APHA 9222D	NG(<1)	$1.0 \ge 10^3$	
Total Coliform Count (cfu/100ml) [Chromocult Agar, (36°C, 24Hours)]	APHA 9223	NG(<1)	$1.0 \ge 10^3$	
Total E. Coli (cfu/100ml [Chromocult Agar, (36°C, 24Hours)]	APHA 9223	NG(<1)	2.0×10^2	
*Enterococcus spp (cfu/100ml)	APHA 9230C	NG(<1)	NG(<1)	

- APHA means American Public Health Association 21st Edition., 2005.

- NG means No Growth 4) cfu- colony forming units

- * means not SAMM accredited parameters.






PedalPure[™] Filtering



www.upsb.com.my | (UPSB Malaysia)



PedalPure[™] Back Flushing

Back Flushing

✓ Please use clean water for Back Flushing.

PSB

- ✓ You may also use with clean water suitable disinfectant.
- ✓ Recommended duration for 20 to 30 minutes



Disclaimer:

Golden Season water filtration systems are designed for emergency response / disaster relief situations. While every effort is made to ensure that the filtered water is fit for consumption, the results of filtration are dependent on water sources, the state of the water filters as well as the equipment competency of the user among other factors.

These products designed for emergencies are to be used at own risk. Neither Golden Season nor any other party (whether or not involved in producing, maintaining or delivering this Website), shall be liable or responsible for any kind of loss or damage that may result due to the use of our product. This exclusion shall include servicing or repair costs and, without limitation, any other direct, indirect or consequential loss.